



Installation instructions: Install clamp bracket just beneath fender with logo on top and with "tick" marks aligned. (Bore of clamp is tapered.) Remove standard mounting bracket supplied with Cyber White lights and discard. Insert stem in main bracket and position links with radius side next to light. Using one link with clearance holes and one with tapped holes, insert 5 MM screws and snug them. Aim lights and tighten all screws. Connect wires to switch and electrical source.

		237 Lewis Harley Road El Dorado, Arkansas 71730 PHONE: (870) 863-5653 FAX: (870) 863-8344	
		MODEL AND DESCRIPTION: GS1150-C	
THIRD ANGLE PROJECTION 	DRAWN: BCG DATE: 2/27/06	COMPUTER FILE # R1150GS, CYBER WHITE BRACKETS	SCALE: NONE REV: 1